







































































**Quick-Garden**








































**SCOOT**




# Assembly instructions



<u>PRODUCT NAME</u>	<u>SCOOT</u>
<u>REFERENCE NUMBER</u>	

No.	Measurement	q	Image		Part name/ Use to:
2	50x70x4341	12			Bearers
3	43x65x4501	3			Wall A, B, E
4	43x65x250	2			Wall E1
5	43x130x6000	1			Wall D
6	43x130x4501	15			Wall A, B, E, E1
7	43x130x2422	7			Wall A
8	43x130x819	24			Wall A, B
9	43x130x893	8			Wall A
10	43x130x449	15			Wall A
11	43x130x1443	8			Wall B
12	43x130x4293	6			Wall D
13	43x130x847	14			Wall D
14	43x130x608	12			Wall C, D
15	43x130x1013	16			Wall C, D
16	43x130x1252	8			Wall D
17	43x130x2452	1			Wall D
18	43x130x6000	7			Wall C
19	43x130x2959	8			Wall C
20	43x130x2554	16			Wall F
21	43x130x250	68			Wall E, E 1, F
21A	43x130x250	10			Wall F
22	43x130x4501	1			Wall E1
23	43x130x268	30			Wall E
24	43x130x2243	15			Wall E
25	43x130x2452	1			Wall C
26	43x130x2452	1			Wall F
27	43x130x2452	1			Wall F
28	43x130x2552	2			Wall C, D
29	43x130x2552	2			Wall C, D
30	43x130x888	2			Wall C, D
31	43x130x1168	2			Wall C, D
32	43x130x4387	2			Wall C, D
33	43x130x4665	3			Wall C, D, F
34	43x130x4665	3			Wall C, D, F

No.	Measurement	Q	Image	Profile	Part name/ Use for:
35	45x1430x4501	3			Roof frame tringle
36	60x130x4501	4			Rafter
37	43x130x2552	1			Rafter
38	43x130x4665	1			Rafter
39	43x130x2552	1			Rafter
40	43x130x4665	1			Rafter
41	60x130x5087	2			Rafter
42	60x130x2974	2			Rafter
43	2900	42,4 m <sup>2</sup>			Roof boards
44	20x105x3000	4			Wind board
45	20x105x3025	4			Wind board
46	16x80x3025	4			Wind board
47	20x105x3610	4			Roof plank
48	25x35x3610	4			Roof plank
49	18x65x6000	5			Ceiling borders
50	2295	19,7 m <sup>2</sup>			Floor boards
51	3395	14,6 m <sup>2</sup>			Floor boards
52	20x35x3403	2			Floor trim
53	20x35x2106	8			Floor trim
54	20x35x2308	8			Floor trim
55	20x35x4255	2			Floor trim
56	20x140x300	2			Decorative diamond Trap
57	2700	1			Trap
58	43x1615x1920	1			Double door
59	43x850x1920	3			Door
60	43x1010x700	7			Window
61	16x80x187/1725	8			Door support trim
62	16x80x187/960	24			Door support trim
63	16x80x810/960	56			Window support trim

Screws			Nails		
	3.5x5	For windows and doors		2.5x6	For boards
	3.5x3	For roof decorative parts			

**IMPORTANT (Read carefully before starting)!**

- The following instructions include both pictures (indicating every part by the digits – see part list above) and illustrations. Please keep in mind that the illustrations are just a general guide to assembling all our products (For example: The illustration on how to assemble a roof applies to all our roofs). However specific models will vary in the quantity of materials needed. By closely consulting the part-list, you will know how many parts you need for each stage of the assembly, while the illustrations will show you how put them together.

- If some extra boards are left over after assembling your product, do not worry. We sometimes include extra boards to ensure that the delivery package is perfectly compact and solid.

**1. General instructions**

**Read carefully before starting.** First of all, we want to thank you for buying one of our products. Please read these instructions carefully before unpacking the parts.

**2. Storing your product prior to assembly.**

Your unpacked product must be stored in a dry, ventilated place, where it is protected from the weather (the package is not waterproof) and direct sunlight. The package and parts should be laid flat on the ground in order to avoid any damage to them. We strongly recommend assembling the product as soon as possible after it is delivered, because any complaints regarding missing or damaged parts can only be made up to 10 days after the date of delivery.

**3. Safety.**

The wooden parts may cause splinters, so please handle them carefully and wear protective gloves. Make sure there are no protruding nails, screws or staples in the assembled pieces. Always follow the instructions carefully and keep to the order of steps.

#### **4.Assembly.**


Before starting to assemble your structure, we strongly recommend that you watch our video guide on our website [www.quick-garden.co.uk](http://www.quick-garden.co.uk) (under the category "Assembly"). During the installation process constantly check that everything is level and parallel. For all parts that need to be assembled using screws, it is advisable to pre-drill holes to avoid the risk of splitting the wood during screwing.

**4.1. Familiarize yourself with the parts.** All parts are numbered, so start by checking that all parts are present by matching them off against your instruction manual. We recommend you sort the parts into separate piles. You will need a rubber hammer, electric screw-driver and anchor screws.

**4.2. Foundation.** Before starting the installation, make sure that the building surface is perfectly flat and level. Lay the foundation elements (PVC blocks, concrete slabs, etc.) For floorless models, the foundation should be at least the same size or larger (recommended) than the external dimension of the structure.




**4.3. Bearers.** The bearers must be placed according to the picture below (general sample) with gaps of around 50 cm between each other. Screw the bearers into the foundation with anchor screws.







**4.4. Assembling the walls:** place the wall-boards on the bearers as shown in a general sample below:




The wall-boards must be placed so that the ends interlock. Now screw the first row of wall-boards into the bearers. All the following rows of placed wall-boards should interlock not only at the ends, but along their length as well. Please screw each new row of wall-boards into the former row to ensure a solid structure.






Wall A




Wall B







### Wall C




### Wall D







### Wall E




## Wall E1




**4.5. Roof frame triangles:** After the walls are assembled, mount the roof frame triangles. These should be mounted as whole structures.




**4.6. Rafters:** The rafters must be mounted horizontally and inserted in the mounting-spaces found on the roof frame triangles. The rafters share a common mounting-space in the middle one of the three triangles. Here are two types of rafter-mounting shown below:







**4.7. Roof-boards:** The next step is to attach the roof-boards vertically and screw them into the rafters. Make sure the ends of the roof-boards are perfectly parallel to each other. Then fix the roof plank boarder under the roof-boards as show below. The roof-plank must be screwed to the roof plank boarder.







**4.8. Wind-boards:** Place the wind-boards on top of each other to make a 90 degree angle. Now attach these ones on a roof frame triangle and fix with screws.




**4.9. Double door:** Assemble the door frame fixing it with screws:



Screw the support trims in to the door frame:



Then insert door frame in to its space from the outside of the structure and attach the rest of the support trims form inside the building.




## Notice:


- Keep in mind that the support trims must be screwed to the door frames, not to the wall-boards!
- Do not worry about the space between the wall and upper window frame. The wood will naturally contract so that the space should disappear within a month or so. Do not try to fill the space in yourself during the assembly process.



**4.10. Single Door:** Screw the support trims in to the door frame:




Insert door frame in to its space from the outside of the structure. Then fix the rest of the support trims from inside the building:






**4.11. Windows:** The windows must be installed in the same way as the doors:

1.




Place the window frame and four support trims on the stable surface.

2.




Drill the holes in the support trims and screw them in to the window frame.

3.




Cut the support trims if necessary

4.




All four support trims are fixed

5.





Just insert the window frame in to the space (no screwing)

6.




Now screw the rest four support trims in to the window frame from the other side.

**4.12. Floor:** Place the floor-boards across the bearers and screw them in at an angle. In this way you will have a screw-free clear floor. After the floor-boards are mounted, screw the floor-boards decorative trims in to the floor-boards.



A, - Bearers  
 B, - Floor-boards  
 C, - Wall-boards

**4.13. Felt roof shingles:** When the whole structure is assembled and has been treated, attach the felt roof shingles to the roof-boards as shown in the picture. We recommend that you cover the roof only after the structure has been treated.



**Treatment.** It is important to treat the product using a quality wood-preserved instantly after the assembly process is finished. Apply at least 2 coats to the outside and 1 to the inside. Repeat annually.

**After-sale service.** Any missing parts or defects must be declared using the After Sales Service form (available in our web site [www.quick-garden.co.uk](http://www.quick-garden.co.uk) or in the last page of this instruction) within 10 days of the product being received. Our After Sales Service will replace defective or missing parts. Make sure you fill in the After-sales service form correctly. After-sale service line + 44 207 097 0013 or [clients@quick-garden.co.uk](mailto:clients@quick-garden.co.uk)

See the terms and conditions of Quick-Garden at [www.quick-garden.co.uk/general-conditions](http://www.quick-garden.co.uk/general-conditions)

Assembly notice – keep for later reference.

We hope you enjoy your purchase.

*Sincerely yours*

*Quick-Garden team*

# Quick-Garden

Customer details: \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

Product model: \_\_\_\_\_

Please name or describe the missing or damaged parts.

Part number	Dimensions	Quantity	Reason for requesting a replacement part