



Quick-Garden

UZES




Assembly instructions



<u>PRODUCT NAME</u>	<u>UZES</u>
<u>REFERENCE NUMBER</u>	

No.	Size, mm			Detail stock	Details	Annotation
	Length	Width	Table			
1	1358	130	58	8		Wall A
2	1876	130	58	8		Wall A
3	2346	130	58	8		Wall A
4	5032	130	58	4		Wall A
5	5032	65	58	1		Wall A
6	2446	130	58	5		Wall A
7	1966	130	58	4		Wall A
8	1966	65	58	1		Wall A
9	4552	130	58	5		Wall A
10	4662	130	58	2		Wall F
11	4662	65	58	1		Wall F
12	1706	130	58	15		Wall F
13	978	130	58	15		Wall F
14	258	130	58	30		Wall F H
15	3499	130	58	4		Wall H
16	3499	65	58	2		Wall H B
17	5032	130	58	1		Wall H
18	3499	130	58	1		Wall H
19	3499	65	58	1		Wall H
20	1966	130	58	1		Wall H
21	2511	130	58	15		Wall H
22	2511	130	58	15		Wall H
23	3617	130	58	5		Wall B
24	3499	130	58	4		Wall B
25	3499	65	58	1		Wall B
26	3381	130	58	5		Wall B
27	1448	130	58	16		Wall B
28	2684	130	58	8		Wall B
29	4316	130	58	9		Wall E C
30	4434	130	58	8		Wall E C
31	5882	130	58	5		Wall C
32	5764	130	58	4		Wall C
33	5214	130	58	8		Wall C
34	3596	130	58	8		Wall C
35	4534	130	58	1		Wall C
36	5864	130	58	1		Wall C
37	2676	130	58	75		Wall D I G
38	2676	130	58	1		Wall I
39	2676	130	58	1		Wall G
40	2666	130	58	2		Wall D
41	5064	130	58	1		Wall D
42	983	130	58	16		Wall D
43	530	130	58	7		Terrace
44	3450	130	58	4		Terrace
45	300	130	58	6		Terrace
46	300	130	58	9		Terrace
47	4316	130	58	1		Wall E
48	3424	130	58	4		Wall E
49	3424	130	58	1		Wall E
50	3306	130	58	4		Wall E
51	3228	130	58	15		Wall E
52	1126	130	58	8		Wall E
53	1138	130	58	8		Wall E
54	3654	130	58	7		Wall E
55	218	65	58	124		In the middle of walls B C E F
56	218	130	58	5		In the middle of walls C E F
57	218	130	58	1		In the middle of wall B
58	218	130	58	4		In the middle of walls C E F
59	2876	130	60	8		Rafters
60	2876	130	60	1		Rafters

No.	Size, mm			Detail stock	Details	Annotation
	Length	Width	Table			
61	5484	130	60	4		Rafters
62	5484	130	60	2		Rafters
63	2400	130	60	1		Support board
64	7000	1040	58	2		Roof frame triangle
65	7000	1040	58	1		Roof frame triangle
66	7000	1040	58	1		Roof frame triangle
67	3850			80,85 m ²		Roof boards
68	4855			24,76 m ²		Floor boards
69	2270			5,7 m ²		Floor boards
70	2520			6,1 m ²		Floor boards
71	1790			4,3 m ²		Floor boards
72	3323			16 m ²		Floor boards
73	1790			7,7 m ²		Terrace floor boards
74	1860			1,7 m ²		Terrace floor boards
75	950	100	22	4		Terrace conection board
76	650	100	22	1		Terrace cover board
77	3580	100	22	1		Terrace cover board
78	950			2		Terrace conection board
79	3950	105	22	4		Wind boards
80	3975	105	22	4		Wind boards
81	3975	60	16	4		Wind board supporter
82	5200	105	22	4		Roof plank
83	5200	35	25	4		Roof plank borders
84	5200	60	18	8		Ceiling trim
85	1800	35	25	5		Floor trim
86	2528	35	25	3		Floor trim
87	2280	35	25	2		Floor trim
88	2400	35	25	10		Floor trim
89	5008	35	25	4		Floor trim
90	3333	35	25	6		Floor trim
91	5020	70	50	32		Bearers
92	1920	850	58	2		Door
93	1920	850	58	2		Door
94	1920	850	58	1		Door
95	1010	1380	58	2		Double Window
96	1010	700	58	5		Window
97	300	140	20	2		Decorative diamond

Screws			Nails		
	3.5x5	For windows and doors		2.5x6	For boards
	3.5x3	For roof decorative parts			

IMPORTANT (Read carefully before starting)!

- **The following instructions include both pictures (indicating every part by the digits – see part list above) and illustrations. Please keep in mind that the illustrations are just a general guide to assembling all our products (For example: The illustration on how to assemble a roof applies to all our roofs). However specific models will vary in the quantity of materials needed. By closely consulting the part-list, you will know how many parts you need for each stage of the assembly, while the illustrations will show you how put them together.**

- **If some extra boards are left over after assembling your product, do not worry. We sometimes include extra boards to ensure that the delivery package is perfectly compact and solid.**

1. General instructions

Read carefully before starting. First of all, we want to thank you for buying one of our products. Please read these instructions carefully before unpacking the parts.

2. Storing your product prior to assembly.

Your unpacked product must be stored in a dry, ventilated place, where it is protected from the weather (the package is not waterproof) and direct sunlight. The package and parts should be laid flat on the ground in order to avoid any damage to them. We strongly recommend assembling the product as soon as possible after it is delivered, because any complaints regarding missing or damaged parts can only be made up to 10 days after the date of delivery.

3. Safety.

The wooden parts may cause splinters, so please handle them carefully and wear protective gloves. Make sure there are no protruding nails, screws or staples in the assembled pieces. Always follow the instructions carefully and keep to the order of steps.

4.Assembly.


Before starting to assemble your structure, we strongly recommend that you watch our video guide on our website www.quick-garden.co.uk (under the category "Assembly"). During the installation process constantly check that everything is level and parallel. For all parts that need to be assembled using screws, it is advisable to pre-drill holes to avoid the risk of splitting the wood during screwing.

4.1. Familiarize yourself with the parts. All parts are numbered, so start by checking that all parts are present by matching them off against your instruction manual. We recommend you sort the parts into separate piles. You will need a rubber hammer, electric screw-driver and anchor screws.

4.2. Foundation. Before starting the installation, make sure that the building surface is perfectly flat and level. Lay the foundation elements (PVC blocks, concrete slabs, etc.) For floorless models, the

foundation should be at least the same size or larger (recommended) than the external dimension of the structure.


4.3. Bearers. The bearers must be placed according to the picture below (general sample) with gaps of around 50 cm between each other. Screw the bearers into the foundation with anchor screws.




THE MESUREMENTS OF THE ACTUAL BEARERS' PLAN:




4.4. Assembling the walls: place the wall-boards on the bearers as shown below:







The wall-boards must be placed so that the ends interlock. Now screw the first row of wall-boards into the bearers. All the following rows of placed wall-boards should interlock not only at the ends, but along their length as well. Please screw each new row of wall-boards into the former row to ensure a solid structure.






The plan of the structure:















4.5. Roof frame triangles: After the walls are assembled, mount the roof frame triangles. These should be mounted as whole structures.




4.6. Rafters: The rafters must be mounted horizontally and inserted in the mounting-spaces found on the roof frame triangles. The rafters share a common mounting-space in the middle one of the three triangles. Here are two types of rafter-mounting shown below.







You can see a plan of the rafters below:




4.7. Roof-boards: The next step is to attach the roof-boards vertically and screw them into the rafters. Make sure the ends of the roof-boards are perfectly parallel to each other. Then fix the roof plank border under the roof-boards as show below. The roof-plank must be screwed to the roof plank boarder.




4.8. Wind-boards: Place the wind-boards on top of each other to make a 90 degree angle. Now attach these ones on a roof frame triangle and fix by screwing them in.



4.9. Door: Screw the support trims in to the door frame:




Insert the door frame in to its space from the outside of the structure. Then fix the rest of the support trims from inside the building:




Notice:


- Keep in mind that the support trims must be screwed to the window or door frames, not to the wall-boards!
- Do not worry about the space between the wall and upper window frame. The wood will naturally contract so that the space should disappear within a month or so. Do not try to fill the space in yourself during the assembly process.




4.10. Windows: The windows must be installed in the same way as the door:




Place the window frame and four support trims on the stable surface.




Drill the holes in the support trims and screw them in to the window frame.




Cut the support trims if necessary



All four support trims are fixed





Just insert the window frame in to the space (no screwing)




Now screw the rest four support trims in to the window frame from the other side.

4.11. Floor: Place the floor-boards across the bearers and screw them in at an angle. In this way you will have a screw-free clear floor. After the floor-boards are mounted, screw the floor-boards decorative trims in to the floor-boards.




- A, - Bearers
- B, - Floor-boards
- C, - Wall-boards

Attach the roof boards according to the plan below:



4.12. Felt roof shingles: When the whole structure is assembled and has been treated, attach the felt roof shingles to the roof-boards as shown in the picture. We recommend that you cover the roof only after the structure has been treated.



Treatment. It is important to treat the product using a quality wood-preservative instantly after the assembly process is finished. Apply at least 2 coats to the outside and 1 to the inside. Repeat annually.

After-sale service. Any missing parts or defects must be declared using the After Sales Service form (available in our web site www.quick-garden.co.uk or in the last page of this instruction) within 10 days of the product being received. Our After Sales Service will replace defective or missing parts. Make sure you fill in the After-sales service form correctly. After-sale service line + 44 207 097 0013 or clients@quick-garden.co.uk

See the terms and conditions of Quick-Garden at www.quick-garden.co.uk/general-conditions

Assembly notice – keep for later reference.

We hope you enjoy your purchase.

Sincerely yours

Quick-Garden team



Customer details: _____

Product model: _____

Please name or describe the missing or damaged parts.

Part number	Dimensions	Quantity	Reason for requesting a replacement part