



Quick-Garden




CLOCKHOUSE

Assembly instructions



<u>PRODUCT NAME</u>	<u>CLOCKHOUSE 5.5X4</u>
<u>REFERENCE NUMBER</u>	

55 x 40 (43)					
	Size, mm			Detail stock	Annotation
	Length	Width	Thick.		
1	5500	130	43	17	Wall B
2	3510	130	43	42	Wall A C D
3	2202	130	43	20	Wall C D
4	227	130	43	64	Wall A
5	4000	130	43	8	Wall C D
6	4000	65	43	2	Wall C D
7	4000	130	43	2	Wall C D
8	4000	130	43	2	Wall C D
9	5960	130	43	2	Wall A B
10	5960	130	60	1	Rafters
11	5960	130	60	4	Rafters
12	2600	110	18	112	Roof boards
13	1750	110	18	22	Roof boards
14	2500	50	40	3	Support boards
15	2500	5	100	1	Support boards
16	3745	100	28	53	Floor boards
17	2700	105	20	4	Wind boards
18	2725	105	20	4	Wind boards
19	1500	105	20	2	Wind boards
20	2200	105	20	1	Wind boards
21	2725	60	16	4	Wind boards borders
22	1500	60	16	2	Wind boards borders
23	5960	105	20	2	Roof plank
24	5960	35	25	2	Roof plank borders
25	5960	60	16	2	Ceiling borders
26	3754	35	25	2	Floor borders
27	5254	35	25	2	Floor borders
28	5340	70	50	9	Bearers
29	4000	1300	43	2	Roof frame triangle
30	2000	1000	43	1	Roof frame triangle
31	1920	1440	43	1	Doors
32	1410	600	43	4	Windows
33	1410	600	43	4	Windows

Screws			Nails		
	3.5x5	For windows and doors		2.5x6	For boards
	3.5x3	For roof decorative parts			

IMPORTANT (Read carefully before starting)!

- The following instructions include both pictures (indicating every part by the digits – see part list above) and illustrations. Please keep in mind that the illustrations are just a general guide to assembling all our products (For example: The illustration on how to assemble a roof applies to all our roofs). However specific models will vary in the quantity of materials needed. By closely consulting the part-list, you will know how many parts you need for

each stage of the assembly, while the illustrations will show you how put them together.

- If some extra boards are left over after assembling your product, do not worry. We sometimes include extra boards to ensure that the delivery package is perfectly compact and solid.

1. General instructions

Read carefully before starting. First of all, we want to thank you for buying one of our products. Please read these instructions carefully before unpacking the parts.

2. Storing your product prior to assembly.

Your unpacked product must be stored in a dry, ventilated place, where it is protected from the weather (the package is not waterproof) and direct sunlight. The package and parts should be laid flat on the ground in order to avoid any damage to them. We strongly recommend assembling the product as soon as possible after it is delivered, because any complaints regarding missing or damaged parts can only be made up to 10 days after the date of delivery.

3. Safety.

The wooden parts may cause splinters, so please handle them carefully and wear protective gloves. Make sure there are no protruding nails, screws or staples in the assembled pieces. Always follow the instructions carefully and keep to the order of steps.

4.Assembly.


Before starting to assemble your structure, we strongly recommend that you watch our video guide on our website www.quick-garden.co.uk (under the category "Assembly"). During the installation process constantly check that everything is level and parallel. For all parts that need to be assembled using screws, it is advisable to pre-drill holes to avoid the risk of splitting the wood during screwing.

4.1. Familiarize yourself with the parts. All parts are numbered, so start by checking that all parts are present by matching them off against your instruction manual. We recommend you sort the parts into separate piles. You will need a rubber hammer, electric screw-driver and anchor screws.

4.2. Foundation. Before starting the installation, make sure that the building surface is perfectly flat and level. Lay the foundation elements (PVC blocks, concrete slabs, etc.) For floorless models, the foundation should be at least the same size or larger (recommended) than the external dimension of the structure.




4.3. Bearers. The bearers must be placed according to the picture below with gaps of around 50 cm between each other. Screw the bearers into the foundation with anchor screws.





	28
	28
	28
	28
	28
	28
	28
	28
	28

4.4. Assembling the walls: place the wall-boards on the bearers as shown below:



The wall-boards must be placed so that the ends interlock. Now screw the first row of wall-boards into the bearers. All the following rows of placed wall-boards should interlock not only at the ends, but along their length as well. Please screw each new row of wall-boards into the former row to ensure a solid structure.




Technical drawing of a building facade showing a symmetrical arrangement of windows and doors. The drawing includes dimensions: a total width of 5500, a height of 12 for the upper section, and a height of 23 for the lower section. The facade features a central entrance with a triangular pediment, flanked by two large windows. Below these are two rows of smaller windows, each row containing four windows. The drawing is a black and white line drawing with dimension lines and numbers.


Technical drawing of a spiral-bound notebook. The drawing shows the front cover and the spiral binding. The dimensions are labeled as follows:

- 12**: The width of the notebook (indicated by a dimension line across the top).
- 23**: The thickness of the notebook (indicated by a dimension line along the right edge of the cover).
- 5500**: The length of the notebook (indicated by a dimension line along the bottom edge).


4.5. Roof frame triangles: After the walls are assembled, mount the roof frame triangles. These should be mounted as whole structures.





4.6. Rafters: The rafters must be mounted horizontally and inserted in the mounting-spaces found on the roof frame triangles. The rafters share a common mounting-space in the middle one of the three triangles. Here are two types of rafter-mounting shown below.




4.7. Roof-boards: The next step is to attach the roof-boards vertically and screw them into the rafters. Make sure the ends of the roof-boards are perfectly parallel to each other. Then fix the roof plank boarder under the roof-boards as show below. The roof-plank must be screwed to the roof plank boarder.




4.8. Wind-boards: Place the wind-boards on top of each other to make a 90 degree angle. Now attach these ones on a roof frame triangle and fix with screws.




4.9. Door: Assemble the door frame fixing it with screws:



Screw the support trims in to the door frame:




Then insert door frame in to its space from the outside of the structure. Finally attach the rest of the support trims to the door frame from the inside the structure.




Notice:

- Keep in mind that the support trims must be screwed to the door frames, not to the wall-boards!
- Do not worry about the space between the wall and upper window frame. The wood will naturally contract so that the space should disappear within a month or so. Do not try to fill the space in yourself during the assembly process.




Clock-vault installation:

*Clock is not included




4.10. Windows: The windows must be installed in the same way as the door:

1.




Place the window frame and four support trims on the stable surface.

2.




Drill the holes in the support trims and screw them in to the window frame.

3.




Cut the support trims if necessary

4.




All four support trims are fixed

5.




Just insert the window frame in to the space (no screwing)

6.




Now screw the rest four support trims in to the window frame from the other side.

4.11. Floor: Place the floor-boards across the bearers and screw them in at an angle. In this way you will have a screw-free clear floor. After the floor-boards are mounted, screw the floor-boards decorative trims in to the floor-boards.



4.12. Felt roof shingles: When the whole structure is assembled and has been treated, attach the felt roof shingles to the roof-boards as shown in the picture. We recommend that you cover the roof only after the structure has been treated.



Treatment. It is important to treat the product using a quality wood-preservative instantly after the assembly process is finished. Apply at least 2 coats to the outside and 1 to the inside. Repeat annually.

After-sale service. Any missing parts or defects must be declared using the After Sales Service form (available in our web site www.quick-garden.co.uk or in the last page of this instruction) within 10 days of the product being received. Our After Sales Service will replace defective or missing parts. Make sure you fill in the After-sales service form correctly. After-sale service line [+ 44 207 097 0013](tel:+442070970013) or clients@quick-garden.co.uk

See the terms and conditions of Quick-Garden at www.quick-garden.co.uk/general-conditions

Assembly notice – keep for later reference.

We hope you enjoy your purchase.

Sincerely yours
Quick-Garden team



Customer details: _____

Product model: _____

Please name or describe the missing or damaged parts.

Part number	Dimensions	Quantity	Reason for requesting a replacement part